































CAUTION - READ MANUAL & ALL NOTES BEFORE INSTALLING OR OPERATING CONTROL. SEE NOTE 1

WARNING: HIGH VOLTAGE



VOLTAGES PRESENT IN THIS CONTROL CAN CAUSE SEVERE OR FATAL INJURIES. NOTE: EVEN THOUGH SUPPLY POWER TO THIS UNIT HAS BEEN DISCONNECTED, THERE MAY BE VOLTAGES IN THIS CONTROL ORIGINATING FROM OTHER SOURCES.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.



CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

CAUTION DO NOT OPERATE WITHOUT WATER ON. POWER ON WITHOUT WATER FLOW MAY CAUSE DAMAGE TO CONTROL. TURN POWER OFF WHEN CONTROL IS HOT IN USE.

Table with columns: QTY, DESIG, PART NO, DESCRIPTION. Lists various components like Terminal Strip, Transformer, Resistor, Fuse, etc.

Table with columns: QTY, DESIG, PART NO, DESCRIPTION. Lists various components like Terminal Strip, Transformer, Resistor, Fuse, etc.

Table with columns: QTY, DESIG, PART NO, DESCRIPTION. Lists various components like Terminal Strip, Transformer, Resistor, Fuse, etc.

Table with columns: QTY, DESIG, PART NO, DESCRIPTION. Lists various components like Terminal Strip, Transformer, Resistor, Fuse, etc.

Table with columns: QTY, DESIG, PART NO, DESCRIPTION. Lists various components like Terminal Strip, Transformer, Resistor, Fuse, etc.